

The configuration of the spare parts

Name	Brand name of origin
Heald wire	Wuxi China
Electrical appliance	Xinliao Ningbo China
Nozzle	Sangyong Korea
Pump spring	Taiwan China
Plunger	Wuxi China
Non-returning valve	Taiwan China
Oil seal	Taiwan China
Soil side length	Qingdao China
Motor	Qingdao Defence China
Front guide roller	Qingdao China
Rear guide roller	Qingdao China
Rocker shaft	Qingdao China
Beam	Qingdao China
Wall board	Qingdao China
Speed changer	Wujiang Jiangsu China or Japan
Brake disc	Huafa Huzhou China
Belt	Sanmen chuanguang China
Bearing bush	Taiwan China
Aluminum parts	Qingdao Datang China
Cloth roller	Qingdao China
Stainless steel	Jiangsu China
Bearing inside the box	NACHI Japan
Dobby	Ox Changfang china
Bearing outside the box	HRB China

If you want the spare parts imported from foreign company, the fee should be paid additionally
The ordinary machine that are with the following parts:

let off : mechanical
take- up : mechanical
cutter : mechanical
plunger : 36*14/26*28/36*28
cloth roller : 1.5pcs
head frame : 4 pcs (for plain); 6 (for dobbie)
but not including the warp beam, loom reed, headle wire

Note :
Due to keeping innovation,
the specification and
Machine pictures or color
are subject to alteration
without notice!